

INSTALLATION INSTRUCTIONS



WR 300

Installation instructions for condensation connection

Condensation is produced during heat recovery and has to be removed via the condensation connection. To do this, correctly connect the ventilation unit with the building's drainage system by using a 3/4" drain hose to link the condensation drain with a siphon.

