


# INSTALLATION INSTRUCTIONS



## DSQ 45/4 K

### Variable installation of ventilation sockets for ESQ K / DSQ K Quickboxes



1 - 2 Variable installation directions