


# WIRING DIAGRAM

## AKE/1



- EA – Exhaust air
- SA – Supply air
- OUT – Output
- OSA – Outer
- IN – Inside