


WIRING DIAGRAM

DSK 31 EC



- X1 mains cable
- X2 control cable
- 5 brown
- 6 black
- 7 yellow
- 8 blue
- 9 green
- 10 violet
- 11 red
- 12 orange