


# WIRING DIAGRAM

## DS 10

### DS 10



DS 10 rotary switch  
2 = continuous operation  
4 = normal operation  
TH 16 thermostat  
M1 fan