


# WIRING DIAGRAM

## DS 3N

### ECR...-A with DS 3N



DS 3N - 3-step switch

Terminals 1-4 are the motor's windings.

Assignment of terminals by way of example:

Minimum speed (terminal 1) is not used here.

# WIRING DIAGRAM

## DS 3N

