

WIRING DIAGRAM

DZR 50/4 B Ex e

