


WIRING DIAGRAM

ECR 20



- FG - Unit release
- XB3 - Operating panel
- X5 - Unit fault
- K - Shutter drive
- V- Exhaust fan
- X11-3 - Open
- X11-4 - Closed
- X11-5 - Slow
- X11-6 - Medium
- X11-7 - Fast