


WIRING DIAGRAM

EZR 50/6 B



With TRE... 5-step transformer.




WIRING DIAGRAM

EZR 50/6 B



With MVE 10-1 motor protection switch




MVE 10-1 not for EZR 25/4 D, EZR 30/6 B and EZR 35/6 B

WIRING DIAGRAM

EZR 50/6 B



With STX / STSX speed controller and MVE 10-1 motor protection switch




MVE 10-1 not for EZR 25/4 D, EZR 30/6 B and EZR 35/6 B

WIRING DIAGRAM

EZR 50/6 B



With TRE... 5-step transformer and MVE 10-1 motor protection switch




MVE 10-1 not for EZR 25/4 D, EZR 30/6 B and EZR 35/6 B

WIRING DIAGRAM

EZR 50/6 B



With contactor circuit (self-switching)



WIRING DIAGRAM

EZR 50/6 B



With STX / STSX speed controller

