


WIRING DIAGRAM

KFR 6030-A



Wiring diagram for KFR 6030-A and KFR 9030-A



TK - thermal contact
