
WIRING DIAGRAM

MS 125



MS 100 / 125 / 150 / 160 - open / closed shutter position



MS 125



MS 100 / 125 / 150 / 160 - shutter position with intermediate settings

