



AKE 150





- Ab - Osigurač na mjestu ugradnje
- mE - Opcija ručnog uključivanja
- S - Upravljanje
- AL - Odsisni zrak
- ZL - Opcija usisnog zraka