



DZF 50/6 B

DZQ/DZS/DZF..B standardni (kretanje udesno, 1 brzina)





SC - Zaštitni kontakt
TK - Toplinski kontakt

DZQ/DZS/DZF..B standardni (kretanje ulijevo, 1 brzina)




SC - Zaštitni kontakt
TK - Toplinski kontakt






DZF 50/6 B



DZF 50/6 B



DZF 50/6 B

