


DZQ 50/4 B

DZQ/DZS/DZF..B standardni (kretanje udesno, 1 brzina)




SC - Zaštitni kontakt
TK - Toplinski kontakt


DZQ/DZS/DZF..B standardni (kretanje ulijevo, 1 brzina)




SC - Zaštitni kontakt
TK - Toplinski kontakt



DZQ 50/4 B



DZQ 50/4 B



DZQ 50/4 B



DZQ 50/4 B

