



DZS 50/4 B

DZQ/DZS/DZF..B standardni (kretanje udesno, 1 brzina)




SC - Zaštitni kontakt
TK - Toplinski kontakt

DZQ/DZS/DZF..B standardni (kretanje ulijevo, 1 brzina)




SC - Zaštitni kontakt
TK - Toplinski kontakt






DZS 50/4 B



DZS 50/4 B



DZS 50/4 B

